

Abstract
This data sheet is for guidance only and must not be used as a substitute for a professional electrical engineer. Hommel Lifts is not responsible for any damage or loss of data or equipment resulting from the use of this data sheet. The user must ensure that the correct specifications and dimensions are used for the product. For more information, please refer to our website www.hommel-lifts.com.

For guidance only HOMMELIFT

Typical Wiring Diagram Data Sheet
(The Standard Variant)



NOTE: UNLESS THE CLIENT REQUESTS PUSH BUTTON CALL STATIONING AND CONCEALED WIRING THE CALL STATION IS TO BE MOUNTED ON THE WALLS OF THE LIFT SHAFT. THE WIRING SHOULD BE CONCEALED IN METAL SUITABLE CONDUIT IN THE WALLS TO SUIT DATE SIZE WITH DRAW STINGS. *ADDITIONAL, 5 CORE CABLE REQUIRED WHICH KEYSWITCH OPTION IS FITTED.

