


NOTE

(*) IF PLATFORM HAS ONLY ONE RAMP, SWITCH S12 (S13) TYPE FR607 IS SUBSTITUTED WITH TWO SENSITIVE EDGES SWITCHES TYPE FR501 ON RAMPLES SIDE

(**) 4 FLOOR SWITCHES ONLY BY PLATFORM WITH SAFETY BOTTOM

POSITION SWITCHES
AUTOMATIC PLATFORM



NOTE

(*) IF PLATFORM HAS ONLY ONE RAMP, SWITCH S12 (*) TYPE FR607 IS SUBSTITUTED WITH TWO SENSITIVE EDGES SWITCHES TYPE FR501 ON RAMPLES SIDE

(**) 4 FLOOR SWITCHES ONLY BY PLATFORM WITH SAFETY BOTTOM

POSITION SWITCHES
MANUAL PLATFORM