

TB 101

TECHNICAL BULLETIN

INFORMATION ONLY

For the Attention of : Service Engineers, Installers, Trade Customers, Training Dept.
Date : 03/08/10
Product : Stairiser SX
Subject : Fold routine revised
Pages : 1

Originator : Stannah Lifts Ltd, Anton Mill, Andover, Hants SP10 2NX 01264 339090

The Stairiser SX software has been revised to modify the sequence in which the platform and barrier arms are folded.

Prior to this change, whenever a fold command was received, the barrier arms would begin to rise first, followed one second later by the platform. This would ensure that the faster folding platform would not clash with the barrier arms on the fold cycle.

It has been reported that under certain circumstances (i.e. permanent activation of the fold button whilst a platform load is present) it is possible to position both barrier arms vertically whilst the platform is left unfolded/accessible.

It should be noted, that to create this situation requires a continual and deliberate effort.

The sequence has been modified to allow the platform to begin folding prior to any barrier arm movement. The platform movement is temporarily paused during the cycle to allow both arms to continue folding thus avoiding any clash.

All contracts manufactured after 16/08/10 will be fitted with the revised controller software.