

**LIFT TYPE:- STANNAH HOMELIFT**

**Re:- New Design Stannah Homelift Concertina Panels.**

**As from the 9th April, 2001, a new design for the Homelift concertina panels is to be introduced to replace the cord and clamp arrangement. The new arrangement is of simpler design and gives easier access for maintenance.**

**The following procedure is for the removal and refitting of the new arrangement.**



Gently slide the middle concertina panel up to reveal the two fixing screws in the front of the bottom panel. Insert a screwdriver or similar instrument into the hole on the side of the concertina panel as shown to hold the middle panel in position while you remove both screws.



Remove the two fixing screws that attach the upper concertina panel to the ceiling infill panel.



Whilst supporting the top panel with one hand, loosen the screw nearest the guides on both sides of the Homelift.



Slide your fingers behind the middle panel and bring the panels towards you. Lower the panels and allow them to gather on the lift cabin.



The concertina panels are now ready to lift away. Ensure all panels are held tightly whilst moving.

Refitting is the reversal of the removal, but take care to locate the two studs of the bottom concertina panel in the top of the cabin.

**Note: In conjunction with this design change, the Homelift cabin has been made 50mm wider to improve access to wheelchair users.**