

SAFETY BULLETIN

For the Attention of : Installers, Lifts Services, Trade Customers

Date : 19/11/07

Product : System 21 Passenger Lifts with Pit Controller

Subject : MRLi Pit Control Panel Cover

Status : Safety Issue

Pages : 1 of 1

Originator : Stannah Lifts Ltd, Anton Mill, Andover, Hants SP10 2NX 01264 339090

Please ensure that the correct manual handling procedures are followed for lifting the cover with outstretched arms and placing it on the floor. Care must be taken to keep a straight back when bending knees and to avoid twisting.

To remove the control panel please follow the guidelines below;

1. Ensure pit floor is clear of tripping obstructions.
2. Remove 2 off screws marked A from control panel cover.
3. Place hands in position B and Lift UP control panel cover approx 30mm; Cover weight is 10kg.
4. Slide cover forward and then down into body and away from control panel to ensure stability when moving.
5. Place against a pit wall that is free of equipment paying special attention to manual handling procedures.

To place the control panel cover back onto the control panel do the reverse of the above again paying attention to the manual handling procedures for lifting awkward objects with outstretched arms.

