

Melody 1 Installation Test Certificate(Page 1 of 3)

B.1. Description of installation:

Lift reference:-

Location:-

Manufacturer:- Terry Group Ltd, Longridge Trading Estate, Knutsford,
Cheshire. WA16 8PR

Lift Description:

Date of Manufacture

Length of travel:

Lift serial No.

Other
identification:

Safe working
load

Rated speed:

Description of lift:

Maximum working pressure:

Pressure relief valve setting:

Electrical supply: a)contract

13A
240V
1 Phase 50Hz

Melody 1 Installation Test Certificate(Page 2 of 3)

B.2. Static Examination

- a) Is all metalwork that encloses live conductors bonded to the main earthing terminal by protective conductors?
- b) Is the platform bonded to earth by a separate conductor?
- c) Does the resistance of the earth protective path exceed .1 ohm?
- d) Insulation resistance to earth. Power circ. safety circuits.
- e) Full load control volts.
- f) Are the platform anti-trapping safety devices adequate?
By for example, an enclosure, guards, bellows, blinds, safety edges or sensitive surfaces.
- g) Do they operate correctly?
- h) Does the platform level to within + or - 12mm on full load?
- i) Is adequate liftway protection provided?
By for example, short flights of steps, strong enclosure 1M above upper level, interlocked + locked gate or barrier.
- j) Are the liftway clearances adequate? (as stated in Specifier's Guide)
That is less than 10mm or greater than 150mm or protected by sensitive edges.
- k) Do the interlocks on the gates operate correctly? Carriage
Upper Level (Optional)
- l) Does the manually operated scotching device operate correctly?
- m) Does the manually lowering valve function correctly?
- n) Does the final limit switch latch operate correctly ?
- o) Does the upper limit switch stop the lift at the upper level?

List any points on which the installation fails to comply:-

Melody 1 Installation Test Certificate(Page 3 of 3)

B.3. BASIC SAFETY SYSTEM CHECKS

Hose condition and connectors

Check call station operation

Check carriage gate interlock operation

Check upper-level gate interlock operation (if fitted)

Check main ram rollers

Check remote control enable operation (if fitted)

Check S/Edges operation

B.4. DECLARATION A

I/We certify that on / / this Steplift was installed to the latest installation instructions and thoroughly examined and found to be free from obvious defects and to comply with the requirements of BS 6440 and that the foregoing is a correct report of the examination.

Signed:-

Qualifications:- Authorised Installer

Address:-

Date:-

CERTIFICATE OF ACCEPTANCE BY PURCHASER/USER

I/We being the purchaser/user of this Melody 1 Steplift (Serial No.) have received, and fully understood, verbal and written instructions, in association with a demonstration, from on its correct and safe use.

Signed:-

Date:-